



ROTOWIPER

'The genuine weedwiper'

Carpet Replacement

- a. Remove Roller from machine by undoing bearing bolts.
- a. Remove old carpet by removing all screws (Bit included with new carpet kit)
- b. Clean roller up. Sand off any rusted areas & treat with rust kill paint.
- c. Silicon old screw holes up to avoid fluid entry into roller after new carpet fitted.
- d. Draw straight line on roller using string as a guide.(fig 1)
- e. Put Roller on Floor
- f. With Carpet in front of you place right hand end on line at edge (Fig 2) and align with your line, fit the first screw in the corner. Pull tight along your line and fit another screw at the end. Fit 4 more screws evenly spaced
- g. Put Roller back up on trestles or similar.
- h. Starting in the centre pull carpet around roller and using sellotape (supplied) as shown (Fig 3) Pull tight and do at least three wraps of tape. It is easier if overlap is upwards.
- i. Repeat every 200mm working out from centre (fig 4)
- j. Using screws supplied starting at centre (Fig 4) put screw in about 20mm from edge, work outwards one side at a time spacing screws spaced every 100mm, when you get to the end fit 2 screws as shown (fig 5)
- k. When both sides are done fit a screw in each gap giving a final spacing of aprox 50mm.



Fig 1 – Drawing line with string



Fig 2 – Fitting carpet



Fig 3 Sellotape



Fig 4 Starting to screw from centre



Fig 5 End screws